

E-Z Connect® Professional Landscape Edging

Installation Guidelines

Using a straight edge spade, make a trench along the bed area where edging is to be installed. Trench should be approximately 4" deep, depending on desired finished edging height.



Slide spike-anchoring adaptors into track system prior to connecting pieces. Recommended spike placement is a maximum distance of 32" apart. Plan to use extra adaptors at or near curves or for additional support when holding back heavier types of decorative stone.



Slide connectors into track system with locking pegs facing toward pre-drilled holes on each edging piece. Locking pegs should click into pre-drilled holes on each of the edging pieces, providing a clean, locked joint without overlapping.



Place edging in the trench with the track groove toward the planting bed. Note that installers may find it easier to connect all pieces before placing edging in trench.



Drive spikes vertically, through loops on spike adaptor until spike head is against the adaptor. Recommended spike placement is a maximum distance of 24" apart. Use extra spikes at or near curves or for extra support when holding back heavier types of decorative stone.



Tightly pack soil around edging and install landscape fabric and ground cover (decorative stone, mulch, etc.) to the top of the edging.

